


SILK CARTRIDGE REMOVAL INSTRUCTIONS


STEP 1

To clean silk nozzles, insert removal tool into grooves on face of silk cartridge.




STEP 2

In a counterclockwise direction, rotate removal tool to loosen silk cartridge.




STEP 3

Remove silk cartridge and clean nozzles.



STEP 4

Insert silk cartridge and rotate removal tool in a clockwise direction to install silk cartridge.




oxygenics®

Pure Shower **Genius**®

INSTRUCCIONES PARA QUITAR EL CARTUCHO DE SILK


PASO 1

Para limpiar las boquillas de silk, inserte la herramienta de extracción en las ranuras de la cara del cartucho de silk.




PASO 2

En sentido antihorario, gire la herramienta de extracción para aflojar el cartucho de silk.



PASO 3

Retire el cartucho de silk y limpie las boquillas.



PASO 4

Inserte el cartucho de silk y gire la herramienta de extracción en el sentido de las agujas del reloj para instalar el cartucho de silk.

